











Note for Connecting

If there is alternator noise (a whining sound when raising engine speed), earth the master unit by connecting it to a metal point of the car with the supplied chassis ground cord ⑩. Connect the earth cord to the master unit with part ② as shown in the illustration. You can use part ① to connect the ground cord to the master unit instead of part ②.

Nota sobre conexión

Si el alternador emite ruido (un zumbido al aumentar la velocidad del motor), conecte la unidad principal a tierra y, para ello, enchúfela a un punto de metal del automóvil mediante el cable de toma a tierra del chasis ⑩ suministrado. Conecte el cable de toma a tierra a la unidad principal con la pieza ② como se muestra en la ilustración. Puede utilizar la pieza ① para conectar el cable de toma a tierra a la unidad principal en lugar de la pieza ②.

ルウアオケイ

ルウ・Xイ(・) 節yカク。]I]-I、'タウトイライスメイ'・Aエコ、@コリシ・sチ。A、AホキIホNイマクqルI、タYイゼ a、アホ、エコqルユアアアエコqルA、AアE、J・iyアア、Eコ C

