



SRS-XB40



4-693-382-12(1)

©2017 Sony Corporation Printed in China





\* 4 6 9 3 3 8 2 1 2 \* (1)




# 1




# 2



# 3




[http://rd1.sony.net/help/speaker/srs-xb40/h\\_zz/](http://rd1.sony.net/help/speaker/srs-xb40/h_zz/)








LIGHT








ON






OFF










Speaker Add



Android iPhone



Wireless Party Chain



Android / iPhone

**SongPal**  
<http://sonyapp.jp/songpal.html>

**Fiestable**